



manikk MIDI THRU Addon v1.1



NOTES!

Type A and B solderpad configuration differs for input jack 1 compared to output jacks 2-8.

Each jack can be configured individually.

Jack 6-8 can be used freely via the tip and ring pins on the pinstrip.

All jacks are STEREO jacks with tip and ring.

All jacks GND are connected to a single common GND.

6 extra GND pins can be found in the pinstrip for general purpose use.

The negative 12V in the power connector are usually marked with a red stripe.